

# Epiphone String Gauges

\*all gauges from Low to High

		Low E (6)	A (5)	D (4)	G (3)	B (2)	E (1)
Acoustic		0.052	0.041	0.034	0.025	0.016	0.012
Acoustic 12 string		0.052	0.041	0.034	0.025	0.016	0.011
		0.025	0.017	0.013	0.009	0.016	0.011
Classical		0.044	0.037	0.029	0.040	0.033	0.029
Resonator		0.056	0.045	0.035	0.028	0.018	0.016
Lennon EJ-160E (electric set)		0.052	0.041	0.030	0.019	0.014	0.011
	Low B	Low E	A	D	G	B	E
Electric		0.046	0.036	0.026	0.017	0.013	0.010
Electric Archtop (large body) *		0.052	0.041	0.030	0.019	0.014	0.011
Electric Archtop (thin line) **		0.046	0.036	0.026	0.017	0.013	0.010
7 string	0.056	0.046	0.036	0.026	0.017	0.013	0.010
Electric 12 string		0.046	0.036	0.026	0.017	0.013	0.010
		0.024	0.017	0.013	0.009	0.013	0.010
	Low B	Low E	A	D	G	C	
Bass 4 string		0.105	0.080	0.065	0.045		
Bass 5 string	0.125	0.105	0.080	0.065	0.045		
Bass 6 string	0.125	0.105	0.080	0.065	0.045	0.040	
Acoustic Bass		0.103	0.078	0.065	0.045		
	Low B	E	A	D	F#	B	
Banjo D tuning	0.011	0.025	0.020	0.014	0.012		
	G	C	G	B	D		
Banjo C tuning	0.011	0.025	0.020	0.014	0.012		
	G	D	A	E			** - 10's
Mando Bird 4 string	0.032	0.024	0.013	0.009			Kat series
							Casino
Mando Bird 8 string	0.032	0.024	0.013	0.009			Dot & Dot Studio
	0.032	0.024	0.013	0.009			Riviera
							BB King Lucille
Mandolin	0.041	0.025	0.014	0.011			Supernova
							Sheraton II
	G	C	E	A			* - 11's
Ukulele - tenor	0.024	0.035	0.028	0.022			Broadway
	D	G	B	E			Emperor Regent
Ukulele - baritone	0.028	0.034	0.030	0.035			ES-295
	A	D	F#	B			Zephyr Regent/Blues Dlx
Ukulele - D tuning	0.028	0.040	0.032	0.026			Emperor II